

Bitte unbedingt vor Inbetriebnahme durchlesen!

Bei Weitergabe des Gerätes an andere Personen ist dieser Benutzerhinweis mit zu übergeben!



Verbinden Sie den Brandstempel mit dem Regler (Steckdose im Gerät)

Verbinden Sie den Regler mit dem Netz. Betreiben Sie den Regler nur mit einer Netzspannung von 230 V Wechselstrom.

Die max. Dauerbelastung des Reglers beträgt 2000 W.

Die Temperaturregelung erfolgt indirekt durch Einstellung des Drehknopfes auf der Skala. Eine gradgenaue Regelung ist nicht möglich. Der Regelbereich beträgt 10-230 V.

Schutzart IP 50, (ausgenommen Schukosteckdose).

Nicht in feuchten Räumen betreiben.

Please read this user manual!

When passing the device on to other persons, this user note is to hand over with!



Connect the fire stamp with the regulator (socket in the device)

Connect the controller to the mains. Operate the controller with only voltage of 230 V AC.

The max. load of the controller is 2000 W.

The temperature control is done indirectly by adjusting the knob on the scale. A degree-exact control is not possible.

The control range is 10-230 V.

Degree of protection IP 50, (except schuko socket).

Do not operate in damp rooms.